

WEATHERBEATER[™] FLOOR LINERS

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater[™] Cargo Liner from Husky Liners. Your new cargo liner is custom molded to fit your Grand Cherokee. Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor or in the cargo area of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates this "relaxing" may take longer; moving the liner to a heated area and letting it lay face-down in a flat position will speed the process.

Your liner is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409[®] or Glass Plus[®] work well. Do not use Armor All[®], Son-of-a-Gun[®] or similar items as these products make the liner slick.



ON JEEP GRAND CHEROKEE 4xe MODELS WITH THE REDUCED STORAGE COMPARTMENT BEHIND THE DRIVER'S SIDE WHEEL WELL, THE CARGO LINER WILL REQUIRE TRIMMING TO ACHIEVE THE PROPER FIT. TO TRIM, USE A PAIR OF SCISSORS AND TRIM USING THE GROOVE IN THE MOLDED IN RAISED RIB IN THE LINER AS YOUR GUIDE. THIS WILL REMOVE THE SMALL SECTION OF THE LINER AS SHOWN IN THE IMAGE ABOVE. A PERIMETER WALL WILL REMAIN TO TRAP SPILLS